

# TOYOTA

## SERVICE BULLETIN

TOYOTA MOTOR SALES, U.S.A., INC.

VOLUME

9

REFERENCE	PRODUCT GENERAL INFORMATION
NUMBER	004
DATE	09-18-87
MODEL	ALL

Page 1 of 4

### 1988 MAINTENANCE SCHEDULE

Since 1986, the majority of Toyota models have a uniform 10,000 miles/12 months maintenance schedule making it simpler for everyone to remember when required maintenance is due.

For the following 1988 models, the normal (Minimum) scheduled maintenance intervals will be as follows:

#### GROUP ONE – PASSENGER CARS AND 4X2 TRUCKS

##### (1) 10,000 Miles/12 Months

Maintenance service, including oil and oil filter change, is required every 10,000 miles or 12 months, whichever occurs first.

1-1	AL	-- Tercel with 3A-C Engine
1-2	EL	-- Tercel with 3E-C Engine
1-3	AE	-- Corolla with 4A-F Engine
1-4	AE	-- FX Corolla with 4A-LC Engine
1-5	AW	-- MR2 with 4A-GZE Engine
1-6	ST	-- Celica with 3S-FE Engine
1-7	MA	-- Supra with 7M-GE Engine
1-8	SV	-- Camry with 3S-FE Engine
1-9	MX	-- Cressida with 5M-GE Engine
1-10	RN	-- 4x2 Trucks with 22R Engine

##### (2) 10,000 Miles/12 Months

Maintenance service, including oil and oil filter change, is required every 10,000 miles or 12 months, whichever occurs first, and an addition of one time idle speed inspection at the first maintenance.

2-1	AE	-- FX Corolla with 4A-GE Engine
2-2	AE	-- Corolla with 4A-GE Engine
2-3	AW	-- MR2 with 4A-GE Engine
2-4	ST	-- Celica with 3S-GE Engine
2-5	YR	-- Van with 4Y-E Engine
2-6	RN	-- 4X2 Truck with 22R-E Engine

## 1988 MAINTENANCE SCHEDULE (Cont'd)

However, the maintenance intervals for the following models are different from above models due to the unique nature of the engine and/or chassis system:

### GROUP TWO – EXCEPTIONS

#### (1) 5,000 Miles/6 Months

Oil change every 5,000 miles or six months, oil and oil filter change every 10,000 miles or 12 months, chassis related maintenance every 20,000 miles or 24 months, and engine related maintenance every 30,000 miles or 36 months, whichever occurs first.

- |     |    |   |
|-----|----|---|
| 3-1 | ST | -- Celica with 3S-GTE Gasoline Turbo Engine     |
| 3-2 | MA | -- Supra with 7M-GTE Gasoline Turbo Engine      |
| 4-1 | RN | -- 4X2 Trucks with 22R-TE Gasoline Turbo Engine |

#### (2) 10,000, 15,000, 30,000 Miles/12, 18, 30 Months

Oil and oil filter change every 10,000 miles or 12 months, engine related maintenance every 30,000 miles or 36 months, and chassis related maintenance every 15,000 miles or 18 months, whichever occurs first and an addition of one time idle speed inspection at the first maintenance.

- |     |    |                                 |
|-----|----|---------------------------------|
| 5-1 | RN | -- 4x4 Trucks with 22R-E Engine |
|-----|----|---------------------------------|

#### (3) 10,000, 15,000 Miles/12 Months, 18 Months

Oil and oil filter change every 10,000 miles or 12 months, engine and chassis related maintenance every 15,000 miles or 18 months, whichever occurs first.

- |     |    |                                  |
|-----|----|----------------------------------|
| 6-1 | FJ | -- Land Cruiser with 3F-E Engine |
|-----|----|----------------------------------|

## 1988 MAINTENANCE SCHEDULE (Cont'd)

### SEVERE SERVICE REQUIREMENTS

Several items require more frequent service under severe driving conditions as described in both the Owners Manual and Repair Manuals. The guidelines for which maintenance schedule to follow – severe to normal – is shown below and in all 1988 Owner's manuals.

### WHICH SCHEDULE TO FOLLOW?

If you mainly operate your vehicle under one or more of the conditions below:

- Towing a trailer, using a camper or car top carrier
- Operating on dusty, rough, muddy or salt-sprayed roads.
- Repeated short trips less than 5 miles (8 km) and outside temperatures remain below freezing
- Extensive idling and/or low speed driving for a long distance such as police, taxi or door-to-door delivery use

Follow  
**SEVERE**  
schedule

If you mainly operate your vehicle under:

CONDITIONS OTHER THAN THOSE LISTED ABOVE

Follow  
**NORMAL**  
schedule

### 1988 MAINTENANCE SCHEDULE (Cont'd)

For your convenience and quick reference, a 1988 Maintenance Schedule Chart is listed below:  
REQUIRED MINIMUM MAINTENANCE SCHEDULE FOR ALL MODELS

X 1,000 Miles Months	05	10	15	20	25	30	35	40	45	50	55	60
	06	12	18	24	30	36	42	48	54	60	66	72
1-1 AL Tercel (3A-C) 1-2 EL Tercel (3E) 1-3 Corolla (4A-FC) 1-4 FX Corolla (4A-LC) 1-5 MR2 (4A-GZE) 1-6 Celica (3S-FE) 1-7 Supra (7M-GE) 1-8 Camry (3S-FE) 1-9 Cressida (5M-GE) 1-104x2 Trucks (22R)		O		OC		OE		OC		O		OM
2-1 FX Corolla (4A-GE) 2-2 Corolla (4A-GE) 2-3 MR2 (4A-GE) 2-4 Celica (3S-GE) 2-5 Van (4Y-E) 2-6 4X2 Truck (22R-E)		Om		OC		OE		OC		O		OM
3-1 Celica (3S-GTE) 3-2 Supra (7M-GTE)	o	O	o	OC	o	OE	o	OC	o	O	o	OM
4-1 4x2 Truck (22R-TE)	o	Om	o	OC	o	OE	o	OC	o	O	o	OM
5-1 4x4 Truck (22R-E)		Om	C	O		OM		O	C	O		OM
6-1 Land Cruiser (3F-E)		O	M	O		OM		O	M	O		OM

o = Oil change only, no filter change  
 O = Oil and filter change  
 m = Inspect idle speed  
 M = Regular Maintenance (Engine and Chassis related maintenance)  
 C = Chassis related maintenance  
 E = Engine related maintenance