

TOYOTA

SERVICE BULLETIN

TOYOTA MOTOR SALES, U.S.A., INC.

VOLUME

10

REFERENCE	PRODUCT GENERAL INFORMATION
NUMBER	<u>032 (REVISED)</u>
DATE	<u>11-02-90</u>
MODEL	<u>ALL MODELS</u>

Page 1 of 3

1991 MAINTENANCE SCHEDULE (REVISED)

For 1991 models, the Toyota Owner's Manual offers 3 maintenance sections within the maintenance chapter following the introduction page as follows:

(1) GENERAL MAINTENANCE

This section describes maintenance items which are the owner's responsibility.

(2) SCHEDULE A

This schedule is for those Toyota vehicles which may require more frequent maintenance, due to severe driving conditions, environment, etc. This was formerly known as the "Severe" schedule.

(3) SCHEDULE B

This schedule is Toyota's minimum maintenance requirement. Items on this schedule must be performed to maintain Toyota's warranty coverage. This was formerly known as the "Normal" schedule.

The highlights of minimum required service, with the exception of high performance models such as those with turbo charged engines, are as follows

- Every 7,500 or 12 months / oil and filter change
- Every 15,000 or 24 months / chassis components service
- Every 30,000 or 36 months / engine and chassis service

A summary of the 1991 maintenance schedule "B" chart for 1991 Toyota models is provided on page 3 of this bulletin for your convenience and quick reference.

1991 MAINTENANCE SCHEDULE (CONT'D)

SCHEDULE "A" REQUIREMENTS

Several items require more frequent service under certain driving conditions as described in both the Owner's and Repair Manuals. The guidelines for which maintenance schedule to follow, i.e., "A" or "B", are shown below and are included in all 1991 Owner's manuals.

WHICH SCHEDULE TO FOLLOW?

If you mainly operate your vehicle under one or more of the conditions below:

- Towing a trailer, using a camper or car top carrier
- Operating on dusty, rough, muddy or salt-sprayed roads
- Repeated short trips less than 5 miles (8 km) and outside temperatures remain below freezing
- Extensive idling and/or low speed driving for a long distance such as police, taxi or door-to-door delivery use

Follow
Schedule
"A"

If you mainly operate your vehicle under:

CONDITIONS OTHER THAN THOSE LISTED
ABOVE

Follow
Schedule
"B"

For an exact description of each model's maintenance requirements, please refer to the appropriate 1991 Repair Manual.

1991 MAINTENANCE SCHEDULE (CONT'D)

REQUIRED MINIMUM MAINTENANCE SCHEDULE "B" FOR 1991 MODELS

Miles (X 1000) Months	7.5 12	15.0 24	22.5	30.0 36	37.5	45.0 48	52.5	60.0 72
MR2 (5S-FE) Celica (5S-FE) Celica (4A-FE) Supra (7M-GE) Camry (3S-FE) Camry (2VZ-FE) Cressida (7M-GE) Previa (2TZ-FE) Tercel (3E-E) Corolla (4A-FE) Corolla (4A-GE) 4x2 Truck (22R-E) 4x2 Truck (3VZ-E) 4x4 Truck (22R-E) 4x4 Truck (3VZ-E)	F	FC	F	FR*	F	FR*	F	FR
Land Cruiser (3F-E)	F	FR	F	FR*	F	FR	F	FR

HIGH PERFORMANCE MODELS:

Miles (X 1000) Months	5 6	10 12	15 24	20	25	30 36	35	40	45 48	50	55	60 72
MR2 (3S-GTE) Celica (3S-GTE) Supra (7M-GTE)	O	F	OC	F	O	FR*	O	F	OC*	F	O	FR

O = Oil change only, no filter change

F = Oil and oil filter change

C = Chassis related maintenance

R = Regular Maintenance (Engine and Chassis related maintenance)

***** = Engine coolant change on all models at 45,000 miles/36 months,
every 30,000 / 24 months thereafter, except Land Cruiser.