



TECHNICAL SERVICE BULLETIN


REF.: AUDIO
NO.: AU91-007
DATE: DECEMBER 27, 1991
MODEL: ALL MODELS

1992 RADIO "TAPE" & "CD" BUTTON ILLUMINATION LOGIC CHANGE

Page 1 of 1


The "TAPE" and/or "CD" buttons on '92 radios are designed so they will illuminate only when these modes of operation are functioning (parking/headlights "ON").

If a Cassette or CD is not inserted and the Parking/Headlights are "ON," the "TAPE" or "CD" buttons do not illuminate. However, the Cassette or CD door, and AM/FM button are illuminated.



ILLUMINATED AREA


When a cassette is inserted with the Parking/Headlights "ON," the cassette door light goes out and the "TAPE" button illuminates.



TAPE ILLUMINATED

When a CD disc is inserted with the Parking/Headlights "ON," the CD door goes out and the "CD" button illuminates.

CD ILLUMINATED



TOYOTA MOTOR SALES U.S.A., INC.