

**Introduction** This Service Bulletin has been prepared to inform you of a supplemental procedure to be performed as part of the FUNCTIONAL OPERATION section of the Pre-Delivery Service for the 2000 model year ECHO.

**Applicable Vehicles**

- All 2000 model year ECHO vehicles.


**Functional Operation** **CHECK ENGINE COOLANT TEMPERATURE WARNING AND INDICATOR LIGHT:**

While performing the Functional Operation checks of the Pre-Delivery Service, use PDS item BO2 to check the Engine Coolant Temperature Warning and Indicator lights.

- The High Engine Coolant Temperature Warning Light is RED.
- The Low Engine Coolant Temperature Indicator Light is BLUE.

Turn the ignition switch to "ON" and check that the High Engine Coolant Temperature Warning Light (RED) comes on for 6 seconds and then goes off.

**NOTE:**  
 When the Engine Coolant Temperature is lower than 140°F (60°C) the LOW temperature indicator light (BLUE) will come on after the HIGH Temperature warning light (RED) goes off.



**Warranty Information**

OP CODE	DESCRIPTION	TIME	OPN	T1	T2
N/A	Not Applicable to Warranty	-	-	-	-