

Special Service Tools

Service Category General

Section Preparation

Market USA

Toyota Supports
 ASE Certification 

Applicability

YEAR(S)	MODEL(S)	ADDITIONAL INFORMATION
2007 – 2009	4Runner, Avalon, Avanza, Camry, Camry HV, Corolla, FJ Cruiser, Highlander, Highlander HV, Land Cruiser, Matrix, Prius, RAV4, Sequoia, Sienna, Solara, Tacoma, Tundra, Yaris	

Introduction

This TSB contains information regarding Special Service Tools (SSTs) applicable to the 2007-2009 model year. Essential SSTs are listed by tool number, tool name, and tool description.

NOTE

Special Service Tools can be ordered through the Toyota/Scion SST Program by calling SPX/OTC at 1-800-933-8335

Required Materials

TOOL NUMBER	SPECIAL SERVICE TOOLS (SSTS)
00002-71368-01	Pry Tool <ul style="list-style-type: none"> Used to assist the technician in removing the glass from the side rear view mirror assembly
09223-75010-01	Oil Seal Replacer <ul style="list-style-type: none"> Used to assist the technician in installing the front oil seal on the 2TR engine.
09308-00010	Oil Seal Puller <ul style="list-style-type: none"> Used to assist the technician in removing oil seals and bearing races

Special Service Tools

Required Materials (Continued)

TOOL NUMBER	SPECIAL SERVICE TOOLS (SSTS)
09387-00090	Bearing Retainer Installer <ul style="list-style-type: none"> Used to assist the technician in servicing the bearing retainer sub-assembly in transaxles
09520-10021	Trans Housing Remover <ul style="list-style-type: none"> Used to assist the technician in servicing the bearing retainer sub-assembly in transaxles. It can also be used to remove drive shafts on some models
09737-00007-01	Brake Push Rod Adjusting Tool <ul style="list-style-type: none"> Used to assist the technician in the proper adjustment of the brake booster pushrod.
09951-00750-01	Replacer 75 <ul style="list-style-type: none"> Used to assist the technician in transaxle and axle disassembly and reassembly.
09951-00770-01	Replacer 77 <ul style="list-style-type: none"> Used to assist the technician in transaxle and axle disassembly and reassembly.
09951-00900-01	Replacer 90 <ul style="list-style-type: none"> Used to assist the technician in transaxle and axle disassembly and reassembly.
09951-01000-01	Replacer 100 <ul style="list-style-type: none"> Used to assist the technician in transaxle and axle disassembly and reassembly.
09951-01100-01	Replacer 110 <ul style="list-style-type: none"> Used to assist the technician in transaxle and axle disassembly and reassembly
09249-37010-01	VVT Set Bolt Wrench <ul style="list-style-type: none"> Used to assist the technician in adjusting Variable Valve Timing.
00002-00039	39 mm Socket <ul style="list-style-type: none"> Used to assist the technician in removing the front axle nut.
09318-12010-8PIN	8 Pin Socket <ul style="list-style-type: none"> Used on steering and suspension applications to remove lock nuts.

Special Service Tools

Required Materials (Continued)

TOOL NUMBER	SPECIAL SERVICE TOOLS (SSTS)
00002-12000-01	KDSS Fluid Pressure Pump Kit <ul style="list-style-type: none"> This pump is used for vehicles equipped with KDSS (Kinetic Dynamic Suspension System). The tool is used to purge air from the system when servicing and to set the ride height.
09521-60010-01	Rear Axle Shaft Puller Adapter <ul style="list-style-type: none"> This adapter is used in conjunction with the rear axle shaft puller tool assisting in removal of rear axle shaft.
09521-25000-01	Rear Axle Shaft Puller Spacer <ul style="list-style-type: none"> This spacer is used in conjunction with the Rear Axle Shaft Puller Adapter to remove a rear axle shaft.
09737-00013-01	Brake Booster Pushrod Gauge <ul style="list-style-type: none"> Used to assist technicians in properly adjusting the brake booster push rod.