



TECHNICAL SERVICE BULLETIN

REF.: ELECTRICAL
NO.: EL93-001
DATE: MARCH 12, 1993
MODEL: ALL MODELS

SUPPLEMENTAL RESTRAINT SYSTEM SERVICE INFORMATION

Page 1 of 1

All Toyota SRS systems are equipped with a back-up power source so the airbag can still be deployed even if the vehicle battery is damaged in a collision.

During vehicle service this means that the airbag could be inadvertently deployed if work is started too soon after disconnecting the negative battery terminal.

Because of slight variations in the Supplemental Restraint System of each model, the period of time specified to wait after removal of the battery terminal now varies (from 20-90 seconds).

New SRS service waiting time specification

To avoid a potential error during servicing of the SRS, the waiting time is being standardized for all models to 90 seconds regardless of what the specification is in the applicable repair manual. Work should not be started until after 90 seconds have passed from the time the ignition switch is turned to the lock position and the negative (-) terminal of the battery has been disconnected.