

Preparation

**Part Number: 00276-00901**

**NOTE:** Part number of this accessory may not be the same as the part number shown.

**Kit Contents**

Item #	Quantity Reqd.	Description
1	4	Wheel Lock
2	1	Key
3	1	Cable Tie
4	1	Port Stuffing Pack w/ID Card

**Recommended Sequence of Application**

Item #	Accessory
1	
2	
3	

\*Mandatory

**Hardware Bag Contents**

Item #	Quantity Reqd.	Description
1		
2		
3		

**Vehicle Service Parts** (may be required for reassembly)

Item #	Quantity Reqd.	Description
1		
2		
3		

**Additional Items Required For Installation**

Item #	Quantity Reqd.	Description
1		
2		
3		

**Conflicts**

--


**Recommended Tools**


<b>Personal &amp; Vehicle Protection</b>	<b>Notes</b>
None	
<b>Special Tools</b>	<b>Notes</b>
None	
<b>Installation Tools</b>	<b>Notes</b>
Socket	21 mm deep well
Torque Wrench	Dial type or Digital 0-100 lbf-ft (135 N-m)
Pliers	With side cutter
<b>Special Chemicals</b>	<b>Notes</b>
None	


**General Applicability**


00276-00970 17" Factory Alloy, 16" Accessory Alloy PT276-30986 16" and 18" Factory Alloy
---


**Legend**


 **STOP:** Damage to the vehicle may occur. Do not proceed until process has been complied with.

 **OPERATOR SAFETY:** Use caution to avoid risk of injury.

 **CAUTION:** A process that must be carefully observed in order to reduce the risk of damage to the accessory/vehicle and to ensure a quality installation.

 **TOOLS & EQUIPMENT:** Used in Figures calls out the specific tools and equipment recommended for this process.

 **REVISION MARK:** This mark highlights a change in installation with respect to previous issue.

 **SAFETY TORQUE:** This mark indicates that torque is related to safety.

## Procedure

Care must be taken when installing this accessory to ensure damage does not occur to the vehicle. The installation of this accessory should follow approved guidelines to ensure a quality installation.

These guidelines can be found in the "Accessory Installation Practices" document.

This document covers such items as:-

- Vehicle Protection (use of covers and blankets, cleaning chemicals, etc.).
- Safety (eye protection, rechecking torque procedure, etc.).
- Vehicle Disassembly/Reassembly (panel removal, part storage, etc.).
- Electrical Component Disassembly/Reassembly (battery disconnection, connector removal, etc.).


Please see your Toyota dealer for a copy of this document.

### 1. Remove One Lug Nut.

- (a) Remove one lug nut from each wheel.


### 2. Install Wheel Lock.

- (a) By hand, install a wheel lock on each wheel.
- (b) Take the key supplied in the wheel lock set. Place it on top of the wheel lock and turn until the patterns engage

-  (c) Place the socket on top of the key. Apply pressure on the key, and using a torque wrench, tighten the wheel locks to 83 lbf-ft (113 N.m).


### 3. Key Storage.

- (a) Attach the key to the vehicle lug wrench using the cable tie. (Fig. 3-1)
- (b) Pull cable tie tight with pliers and cut off excess with side cutters.

-  (c) Place the lug wrench with the key attached in the vinyl tool pouch.

### 4. Complete the Installation.

-  (a) Place the wheel lock information packet in the glove compartment.




**TOYOTA TACOMA 2005 - WHEEL LOCK**

Checklist - these points **MUST** be checked to ensure a quality installation.

Check:

Accessory Function Checks

- Correct part number has been installed
-   Wheel lock tightness
  
- Key storage
  
- Complete installation

Look For:

- Verify part number on package
- Wheel locks have been installed at a torque of 83 lbf-ft (113 N.m). Verify process only – check torque during installation
  
- Lug wrench with the key attached in the vinyl tool pouch
  
- Wheel lock information packet in the glove compartment