



**Technical Service
BULLETIN**

August 18, 2006

Title:

**GAP BETWEEN REAR FENDER FLARE
& BUMPER**

'07 FJ Cruiser

**BODY
B0017-06**

Introduction Some customers may notice that after taking their vehicle through a car wash, there is a gap between the fender flare and the rear bumper. New fasteners are available to correct this condition.

- Applicable Vehicles**
- **2007** model year **FJ Cruiser** vehicles produced **BEFORE** the Production Change Effective VINs shown below.

Production Change Information

MODEL	MODEL CODE	PRODUCTION CHANGE EFFECTIVE VIN
FJ Cruiser	GSJ10	JTEZU11F570004023
	GSJ15	JTEBU11F970021523

Parts Information

PREVIOUS PART NUMBER	CURRENT PART NUMBER	PART NAME	QTY
N/A	90189-06098	Screw Grommet	2
N/A	90159-60603	Self-tapping Screw w/Washer	2

Required Tools & Material

TOOLS & MATERIAL	QUANTITY
Miscellaneous Hand Tools	As Needed

Warranty Information

OP CODE	DESCRIPTION	TIME	OFF	T1	T2
BD5035	R & R Fender Flare Retainers	0.5	75495-35010	67	57

Applicable Warranty*:


This repair is covered under the Toyota Comprehensive Warranty. This warranty is in effect for 36 months or 36,000 miles, whichever occurs first, from the vehicle's in-service date.

* Warranty application is limited to correction of a problem based upon a customer's specific complaint.




Repair Procedure

1. Disconnect the cable from the negative (-) battery terminal.
2. Remove the rear bumper cover.
 - A. Apply protective tape as shown in the illustration.




- B. Remove the seven (7) bolts and two (2) screws.
 - If the vehicle has Park Assist, continue to step C.
 - If the vehicle does NOT have Park Assist, go to step D.




**Repair
Procedure**
(Continued)

- C. **Vehicle with Park Assist:**
Disconnect the two (2) wire to
wire connectors.



- D. Disengage the six (6) claws and
two (2) clips.
- E. Remove the rear bumper.




**Repair
Procedure**
(Continued)

NOTE:

Perform the following steps on both the LH and RH sides.

3. Disengage and remove the lower clip at the rear of the fender flare.



4. Install the NEW screw grommet into the hole in the sheet metal under the fender flare.
5. Use the NEW self-tapping screw to secure the lower fender flare.
6. Reassemble in reverse order of disassembly.